MEDER
GUIDING EXPERIENCE





Der MINIMALIST 2.0 –
even simpler, even more features, even more ingenious

MEDER

EasyGuide 2

1 TURN ON THE TRANSMITTER

Slide the side switch on the transmitter to “**ON**”.

2

The transmitter is ready for use immediately after being turned on.

3

The display shows, among other things, the channel, battery level, and transmission volume.

4

If necessary, connect a headset or external microphone to the 35-mm jack.

You can adjust the transmission volume using the “**+**” and “**-**” buttons



1. Built-in microphone
2. Power and key lock
3. OLED-Display
4. Menu button
5. Mute button
6. Pairing button
7. OK button
8. +/- button (Navigation/microphone volume)
9. Navigation buttons

1 TURN ON THE RECEIVER

Press and hold the “On/Off” button on the receiver for about 2 seconds.

2

The display shows the battery level and channel.

3

The status LED indicates the connection status:

- slow flashing (approx. every 3 seconds) = connected to the transmitter
- fast flashing (approx. every second) = no connection



1. On/Off button
2. Display
3. Status-LED
4. Charging Port
5. Volume “**+**” / “**-**” button

When a connection is established, the displayed channel corresponds to the station‘s channel.

1 *Connect the Receiver*

Plug the charging case into a power source and turn it on.



2

Place the **powered-on** transmitter in the transmitter detection area on the right side of the charging case.

3

The LEDs at the loading stations light up **bright green** as soon as the configuration has been successfully transferred.

Without the charging case:

Press and hold the “**PAIR**” button until “**PAIRING**” appears.
Turn on the receiver near the transmitter—the connection will be established automatically.

MEDER EasyGuide2
Pair a receiver



1. Document tray
2. UV disinfection lamp
3. Status indicators for the charging stations
4. Charging stations for the receivers
5. Mount for the charging cable
6. Transmitter mount
7. Power switch
8. 2 USB ports for charging the transmitter and the UV lamp
9. Transmitter detection range

Once configuration is complete, the receivers are connected to the transmitter and ready for use.

Get free advice on our accessories for the **EasyGuide2.**
Call our Service Center or visit our website for more information:

www.meder-guiding.de

Illustrations are for illustrative purposes only.

Subject to change without notice.

The complete user manual and Quick Start Manual for the **EasyGuide2** are available at the following web address:

www.meder-guiding.de/service/downloads/

Imprint

MEDER CommTech GmbH
Robert-Bosch-Str. 4
78224 Singen, Deutschland
Tel: +49 (0)7731 911 322 0
Fax: +49 (0)7731 911 322 99
info@meder-commtech.com
www.meder-guiding.de